RTX3 Wireless Expansion Module V5.3 Addendum

 $R riangleq D O X^{\epsilon}$

The following information has not been included in the RTX3 Reference and Installation manual. The information detailed in this addendum applies to the RTX3 Module V5.3.

Wireless Siren support for EVO via RTX3

The RTX3 Wireless Expansion Module now provides the ability to support the Paradox wireless sirens (SR130 and SR150). Please note that only one RTX3 Module can be assigned to the Wireless Sirens.

In order to take full advantage of this new feature, a firmware update will be required. The following table provides product compatibility.

Product	Required Version
EVO192	v3.20
EVOHD	v1.20
SR150	v2.30
SR130	v1.10
BabyWare	v2.30

Before beginning, ensure that the serial number of the RTX3 Module has been programmed, this is achieved via section [2850]. Once the RTX3 module has been programmed, the wireless sirens can be programmed either by BabyWare or with a keypad.

To Program the Wireless Sirens via BabyWare

Configure wireless sirens with BabyWare v2.30 and up.

- 1. Open BabyWare.
- 2. Right-click on the EVO192/EVOHD panel in the Control Panel field.

The Control Panel drop-down menu opens.

3. Select **Properties**.

The Control Panel window opens.

4. Select the Wireless Sirens field.

The Areas/System/Wireless Sirens window opens.

- 5. Select the Wireless Sirens tab.
- Configure the following fields:
- RTX3: Select the RTX3 module from the RTX3 Assignment drop-down menu
- TX Serial#: Enter the wireless siren's 6-digit Serial number
- Assign a Label
- Assign Partition/s (partitions 1-8)

IMPORTANT: Wireless sirens can only be assigned to either a single partition or to all partitions.

- 7 Select OK
- 8. Select a Location for the wireless siren in the Main window.
- 9. Select the **Add Item** button in the Main window to add the wireless siren/s.

The wireless siren is configured.

Printed in Canada 05/2015 RTX3-EA00

Programming Wireless Sirens with Keypads

Program wireless sirens with supported keypads.

Step	Option	Section	Description
1	Assign RTX3	[2850]	Assign the RTX3 that the sirens will be configured to.
2	TX Serial #	[2851]-[2858]	Program the 6-digit TX Serial number of each wireless siren (corresponding to serial numbers for wireless sirens1-8).
3	Assign Partition(s)	[2861]-[2868]	Assigning partitions to each siren (corresponding to partitions 1-8). IMPORTANT: Wireless sirens can only be assigned to either a single partition or to all partitions.
4	TX Signal Strength	[2871]-[2878]	Display the wireless siren signal strength (corresponding to wireless siren 1-8). Note: The signal strength level is measured from 1-10. An acceptable signal strength is signal level 4. Signal strength level is displayed on the keypad by an asterisk (*). EXAMPLE: (*****) represents signal level 4 on th keypad.

Printed in Canada 05/2015 RTX3-EA00